

SEASIDE CASUAL FURNITURE

ENVIRO WOOD

(28) Adirondack Foot Stool rev. A

Parts List:

- (1) Foot Stool
- (2) Legs



Hardware:

- (6) 2-3/4" Connector Bolts
- (6) Flat Washers
- (6) Lock Washers
- (6) Nuts

Tools Required:

- 7/16 Socket or Wrench
- 4MM Allen Wrench (Included)

Assembly Instructions

Step One: Set Up

READ ENTIRE INSTRUCTIONS BEFORE BEGINNING! Carefully remove contents from box. Make sure that all parts and hardware are included.

Step Two:

Place footstool upside down on a flat clean surface. Place Leg inside Foot Stool with highest point of the angle end facing front brace and align (3) pre-drilled holes with Foot Stool. Install leg using (3) 2-3/4" connector bolts through the outside of the footstool pre-drilled holes and through the pre-drilled holes in the leg. Finger tighten bolts with flat & lock washers and nuts. Do not tighten at this time. Repeat this process for the other leg.



Step Three: Tightening of Hardware

Tighten all connections. **Do not over tighten!!! Over tightening of hardware can cause damage to the item.**